Flour fortification in SEA – addressing technical concerns

4th Annual Southeast Asia District Conference October 8-10, 2013

Lena Kampehl Research & Development Vitamin Premixes Stern-Wywiol Gruppe GmbH & Co. KG, Germany



Agenda:



Implementation of WHO guidelines



Impact on colour



Interaction with flour improvers



WHO recommendation

Nutrient	Flour Extraction Rate	Compound	in parts per millio		rient to be added on (ppm) by estimated at flour availability (g/day) ¹	
			<75² g/day	75-149 g/day	150-300 g/day	>300 g/day
Iron	Low	NaFeEDTA	40	40	20	15
/ \		Ferrous Sulfate	60	60	30	20
Ferrous Fumarate Electrolytic Iron		Ferrous Fumarate	60	60	30	20
		Electrolytic Iron	NR³	NR ³ 50	60	40
	High	NaFeEDTA	40	40	20	15
Folic Acid	Low or High	Folic Acid	5.0	2.6 2.0	1.3	1.0
Vitamin B ₁₂	Low or High	Cyanocobalamin	0.04	0.02	0.01	0.008
Vitamin A	Low or High	Vitamin A Palmitate	5.9	3	1.5	1
Zinc ³	Low	Zinc Oxide	95	55 30	40	30
	High	Zinc Oxide	100	100	80	70

Iron is not just iron



	Appearance	Iron content	Bio- availability	Reactivity
Electrolytic iron		97%	50-75%	↓
Ferrous fumarate		32%	100%	1
Ferrous sulfate		32%	100%	↑ ↑

Impact of different iron sources on final products



Example: Pasta enrichment

	0	1	2	3	4	5	6
Iron source	Non-enriched	Ferric pyro- phosphate	Ferric ortho- phosphate	Electrolytic	Ferrous fumarate	Ferrous sulfate	Ferric sodium EDTA
Relative bio- availability (WHO)		21-74%	25-32%	50-75%	100%	100%	>100%
Appearance compared to non-enriched pasta		Comparable	Comparable	Comparable	Brighter	Greyish	Much brighter
Pictures			额				6

Magnetism



- Electrolytic iron is ferromagnetic = constantly magnetic
- Ferrous fumarate is paramegnatic = magnetizeable





Increased zinc level Influence on the rheological characteristics

Example: Wheat flour

A saline Bonn	Davis	Content of active	FARINOGRAPH			EXTENSOGRAPH		
Active agent	Raw material	agent in flour (ppm)	WA	Develop- ment time	Stability	Resis- tance	Extensi- bility	Energie
Zinc	Zinc oxide	15	=	=	=	=	=	=
		30	=	=	=	=	=	=
		40	=	=	=	=	=	=
		60	=	=	=	=	=	=
		80	=	=	+	+	+	+
		120	=	=	+++	+++	+++	+++



Increased folic acid amount - Impact on colour?







Determination of the colour



Measurement with L*a*b*Colorimeter


L= Lightness (0=black, 100=white)

a= position between red (0 to 60) and green (0 to-60)

b= position between blue (0 to-60) and yellow (0 to 60)

Comparing the results:

Colour distance	Deviation		
$\Delta b_{S0S1} < 0.5$	not visible		
$0.5 < \Delta b_{S0S1} < 1.0$	very low		
$1.0 < \Delta b_{SOS1} < 3.0$	low		
$3.0 < \Delta b_{S0S1} < 6.0$	medium		
$6.0 < \Delta b_{SOS1}$	high		




Graphical representation of the L*a*b* colour space model



Increased folic acid amount – Impact on the colour of flour



	b*- value	Deviation from non-enriched flour		
Non-enriched flour	+6.15			
Flour with 2 ppm folic acid	+6.24	0.09	not visible	
Flour with 2.6 ppm folic acid	+6.28	0.13	not visible	






Increased folic acid amount – Impact on the colour of bread



	b*- value	Deviation from non-enriched bread		
Non-enriched bread	+14.03			
Bread with enriched flour (2 ppm folic acid)	+14.24	0.21	not visible	
Bread with enriched flour (2.6 ppm folic acid)	+14.35	0.32	not visible	






Interaction between flour improvers and fortificants



Bleaching agents

- Example: Malaysia
 - Benzoyl peroxide 50ppm
 - Vitamin premix (B vitamins and iron)
- SGS analysis every year since 2007
- Results always within specification
- → No interaction in flour



SGS Germany GmbH Laboratory Services Hamburg

Vitamin B1 - HPLC (DIN EN 14122)

Vitamin B2 - HPLC (DIN EN 14152)

Niacin

Vitamin B1

Vitamin B2

Dr. Roy Hürner (Laborislety) / Ingrid Bujarra (Analytical Consultant Food)
Stephaner Rotice (Analytical Consultant Food) - Jessica Monaumi (Analytical Consultant Food)
*N.A = Not analysed, *N = Test not accreditated, *S = Test subcontracted, < = less than

The results refer only to the analysed samples. Information about the measurement uncertainties will be given on request. The duplication of the test reports and expertises in parts is not allowed without written consent of the SGS Germany GmbH

Substitute 12 0.2005 flamburg 1 +64 (3.2016) - 0 1+64 (3.2023) www.ofs.sigs.com institution intend spream, like of minimize flamburg, placed language flowing and professional minimization of a second real flamburg of the substitution of the subst

Page 1 of 1

Interaction between flour improvers and fortificants



Ascorbic acid

- Case study from Brazil
 - Premix: Ascorbic acid + vitamin mix with iron
 - Discoloration of premix after 1-3 days (30°C/80% r.H.)
 - Reaction between ascorbic acid and iron

1h /30°C/80%



coarse (l.) and fine (r.) ascorbic acid with vitamin/iron mix

18h /30°C/80%



coarse (l.) and fine (r.) ascorbic acid with vitamin/iron mix

→ Different feeders

Thank you for your attention!

